





Care/Cleaning Instructions:

- Ensure your toy is switched off and the charger is completely disconnected before cleaning.
- We suggest cleaning your toy with toy cleaner or warm water and soap before and after each use. Be sure to clean in between each petal.
- Use caution when cleaning your toy. Moisture in the battery component can cause malfunction.
- Use the storage pouch provided and be sure to keep your toy separate from products made with different materials.
- Be sure to let your toy dry completely before storing.
- Store in a clean, cool and dry place. Do not expose to direct sunlight.



Charging Instructions:

- All products come with a factory charge. We suggest fully charging your toy before use.
- Only use the charger provided to charge your toy. Using any other charging base may cause malfunction.
- Do not charge your battery in or around water.
- The Classic Rose features a magnetic charging base; simply place your Rose on the charging base so the magnetic charging connectors hold the toy firmly in place.
- The Classic Rose indicator light will blink while the toy is charging.
- When your toy is fully charged, light will remain steady.
- Full charging time is 1.2 hours.
- Play time is approximately 1 hour.



How to Bloom Orgasms:

- Allow your toy to fully charge before play.
- Press and hold the bottom function button for 3 seconds to turn on/off your Classic Rose. Red indicator light will become illuminated when the unit is powered on.
- Press the function button to toggle through the 10 suction functions.
- To turn off, hold down the function button for 3 seconds, indicator light will turn off when the unit is fully powered down.
- Do not use your toy on swollen, bruised or inflamed areas including skin lacerations.
- Discontinue use immediately if irritation or discomfort occurs.